## **TELEDYNE ANALYTICAL INSTRUMENTS**

www.teledyne-ai.com

## **MODEL 306 STARTUP PROCEDURE**

**Equipment:** Digital multi-meter (DMM)

Gas: High purity grade nitrogen or better Electrolyte: Type A or Type C electrolyte

## **Procedure:**

1. Connect the power cord as follow:

HOT to terminal TS1-14 NEUTRAL to terminal TS1-13 GROUND to terminal TS1-12

- 2. Position ON/OFF switch to ON.
- 3. Connect DMM across HOT and NEUTRAL. The DMM reads  $40 \pm 10$  ohms (115 VAC),  $160 \pm 30$  ohms (220 VAC).
- 4. Connect DMM between HOT and GROUND. The DMM reads infinite.
- 5. Fill the reservoir with 1000 cc of distilled water.
- 6. Connect the nitrogen to the analyzer's sample inlet.
- 7. Close sample flow valve inside the analyzer. Do not over-tighten the valve.
- 8. Turn on the nitrogen and adjust the sample flow valve until the ball in flow tube is in the target.
- 9. Follow instructions sent with electrolyte kit to mix the electrolyte.
- 10. Unpack the cell, remove the cover (the cell is packed with water when it ships from the factory), and dump the water.
- 11. Remove the calibrator and wet it with Type A electrolyte. Use a paper towel to wipe the excessive liquid. Replace calibrator.
- 12. Pour electrolyte into the cell over the top of screen. Shake the cell a bit and empty the cell. Slowly fill in the electrolyte until the screen in the liquid is approximately 3/32 inch.
- 13. Install the cell to the analyzer. Do not connect the cell cable at this time. Let the analyzer purge with nitrogen for 1 hour.
- 14. Position range switch to 3.
- 15. Connect power cord to power source.
- 16. Connect cell cable, red lead to center post and black lead to outer post.
- 17. Advance the range as the reading goes below 10% of scale.
- 18. Wait until the reading drops below 1 ppm or it stabilizes, if the nitrogen contains some oxygen.
- 19. Verify the flow indicator at the target.
- 20. Set calibrator pot to 75 ppm.
- 21. Position range switch to 100 ppm.
- 22. Position calibrator switch to ON.
- 23. As the reading starts to increase, wait until the reading stabilizes, and adjust span pot so the analyzer meter reads 75 ppm.
- 24. Set calibrator pot to 50 ppm. Wait until the reading stabilizes and the analyzer meter reads  $50 \pm 2$  ppm.
- 25. Set calibrator to 25 ppm; analyzer meter reads  $25 \pm 2$  ppm.

**NOTE**: when the sample contains more than 1 ppm oxygen, see manual for correct span adjustment value.

- 26. Position calibration switch to OFF.
- 27. Advance range switch when the reading goes below 10% of scale.