


ISSUE NO.	APP.
5) ECD#92-259 3-10-80	ME



- \*NOTE:**
1. UNITS ARE SHIPPED WITH BATTERY WIRES DISCONNECTED. WHEN READY TO START UP UNIT, CONNECT WH-GN WIRE TO PIN 6 OF TERMINAL STRIP, THEN CONNECT RED WIRE TO PIN 5 OF TERMINAL STRIP.
  2. DO NOT PLUG IN AC PRIOR TO CONNECTING THE BATTERY WIRES.

AC POWER IN

LINE  
NEUT.  
GND.

THIS DRAWING IS THE PROPERTY OF TELEDYNE ANALYTICAL INSTRUMENTS AND CONTAINS CONFIDENTIAL INFORMATION. IT IS NOT TO BE COPIED, REPRODUCED OR USED WITHOUT WRITTEN PERMISSION.			
TOLERANCE UNLESS OTHERWISE SPECIFIED	FRACT. ± 1/64	DEC. ± .005	ANGULAR ± 1/2°
<b>TELEDYNE ANALYTICAL INSTRUMENTS</b> SAN GABRIEL, CALIFORNIA		SCALE NONE	DATE 9/26/80
		MATL: ~	
MDL. 335-1 OXYGEN ANALYZER INTERCONNECTION DIAGRAM S.O. 10578		FINISH: ~	
		DR FCO	ENGR. APP
		A-24690	